


UCTRONICS STARTER KIT

KB0006 Packing List

The Raspberry Pi Pico is not included !



NOTE

The LCD display included in the kit is slightly different from what's been used in the book, so please refer to following wiring and code instead.


Git Clone <https://github.com/UCTRONICS/KB0005.git>

x12 Colorful LEDs	x1 WS2812B LED strip	x1 Solderless breadboard	x30 SoldeJumper wires: 10pcs each of male-to-female (M2F), male-to-male (M2M) and female-to-femaleless breadboard	x5 Push-button switches
x1 micro USB cable with switch button	x1 HC-SR501 PIR sensor	x1 Active piezoelectric buzzer	x1 1602 LCD module	
x1 Spare header	x1 10 kΩ potentiometer	x10 330 Ω resistors		

UCTRONICS STARTER KIT

KB0006 Packing List

The Raspberry Pi Pico is not included !



NOTE

The LCD display included in the kit is slightly different from what's been used in the book, so please refer to following wiring and code instead.

Git Clone <https://github.com/UCTRONICS/KB0005.git>

x12 Colorful LEDs	x1 WS2812B LED strip	x1 Solderless breadboard	x30 SoldeJumper wires: 10pcs each of male-to-female (M2F), male-to-male (M2M) and female-to-femaleless breadboard	x5 Push-button switches
x1 micro USB cable with switch button	x1 HC-SR501 PIR sensor	x1 Active piezoelectric buzzer	x1 1602 LCD module	
x1 Spare header	x1 10 kΩ potentiometer	x10 330 Ω resistors		